



35MM PAPER LEADER FOR MEDIUM FORMAT CAMERAS
CUT THE PAPER LEADER OUT OF AN EXPOSED 120 FILM'S BACKING PAPER
AND USE IT AS A 35MM FILM STARTER IN YOUR MEDIUM FORMAT CAMERA

WWW.CAMERHACK.IT

